

Mobile grid support



- Mobile easy-to-store cabling support. (Supplied without grid)
- On a bench, the work area (grids or panels) can be angled by the cabler simply by using the screw handles on the sides.
- The ball joints in contact with the table adjust automatically according to the work angle.
- The holding bars make the assembly very rigid for comfortable working.
- Adjustable horizontal and vertical rails for using grids with varied dimensions.
- This system also takes wood panels 12mm thick and BA13 plaster panel.
- Overall dimensions of the main frame: 1000 x 750mm
- Maximum dimensions of the work area: 800 x 750mm (panels or grids)
- Footprint on table in maximum open position: 750 x 530 mm

ref. FREE-SUP-O

ref. FREE-SUP-V

