



Discover more details and matching accessories online!

Stainless steel floor scale with screwed-on weighing plate (IP67) and stainless steel display device (IP68), verification optional

Features

- Tough industry standard suitable for use in harsh industrial applications
- **1** Weighing plate screwed on from the top with stainless steel screws, so it's easy to remove, hygienic and easy to clean
- Weighing bridge: stainless steel, extremely resistant to bending due to material thickness, 4 hermetically welded stainless steel load cells, IP68 dust and spray protection
- Easy levelling of the weighing bridge as well as access to the junction box from above
- Display device: stainless steel, protection against dust and water splashes IP68, for details see KERN KXC-TM
- IoT line: networkable balances with user-friendly concept of operation

- The exchange of data and control commands is optional using up to four interfaces to suit individual requirements: two wired connections and two wireless connections, for details see KERN KXC-TM
- Available as an option with alibi memory for paperless archiving of weighing results. This also means the results of weighings with mandatory verification can be electronically evaluated and processed further
- Wall mount for display device, standard

Technical data

- Large backlit LCD display, digit height 48 mm
- Weighing platform dimensions W×D×H, stainless steel
 - A** 1000×1000×85 mm
 - B** 1500×1250×85 mm
- Dimensions of display device W×D×H 232×150×77,3 mm
- Cable length of display device approx. 5 m
- Permissible ambient temperature -10 °C/40 °C

Shipment via freight forwarder. Please ask for dimensions, gross weight, shipping costs

STANDARD

OPTION

FACTORY

Model	Weighing capacity [Max] kg	Readability = Verification value [d] = [e] kg	Minimal load [Min] kg	Net weight approx. kg	Weighing plate	Price excl. of VAT ex works €	Options			
							Verification	€	Calibr. Certificate	€
KERN									DAkkS accr.	
							KERN		KERN	
BXC 600K-1SM	600	0,2	4	100	A	3020,-	965-230	166,-	963-130	225,-
BXC 1.5T-4SM	1500	0,5	10	100	A	3020,-	965-230	166,-	963-130	225,-
BXC 1.5T-4M	1500	0,5	10	150	B	3840,-	965-230	166,-	963-130	225,-
BXC 3T-3M	3000	1	20	150	B	3990,-	965-232	245,-	963-132	610,-

Note: For devices that require verification (conformity assessment according to NAWI 2014/31/EU), please include the verification when placing your order.
The initial verification is not possible after delivery. Please inform the full address of the location of use for the initial verification.
Note: For verified scales the weighing bridge should be fixed to the floor. Optionally, with an access ramp, a footplate pair or a pit frame