

MA160 True RMS 200A AC/DC Open Jaw Clamp Meter



Open jaw design provides quick current measurements in tight locations without breaking the circuit. True RMS provides accurate readings on noisy, distorted or non-sinusoidal waveforms. Convenient built-in Non-Contact Voltage (NCV) Detector allows quick detection of live voltages while the LED backlight, with two level brightness, and flashlight help take measurements in dimly lit environment.



Features

- 0.57" (14.5mm) open jaw size allows current measurements in tight spaces
- Built-in Non-Contact Voltage (NCV) detector with audible alert and LED indicator
- Relative Mode for Capacitance Zero and offset adjustment
- 2000 count 2-level backlit LCD display
- Convenient LED worklight for viewing in dimly lit area
- Continuity and Diode Test
- Auto Power Off with disable
- Ergonomic housing with built-in test lead holders
- CAT III-600V rating
- Complete with test leads, two AA batteries, and pouch

Specifications	Range	Basic Accuracy
AC/DC Current	200A (0.1A)	$\pm(2.5\%+5d)$
AC Voltage	750V (1mV)	$\pm(2.5\%+3d)$
DC Voltage	1000V (1mV)	$\pm(0.8\%+3d)$
Non-Contact Voltage (NCV)	100 to 750V	
Resistance	60M Ω (0.1 Ω)	$\pm(1.0\%+2d)$
Capacitance	60mF (0.01nF)	$\pm(4.0\%+20d)$
Continuity /Diode Test	Yes	
Dimensions	8.3x2.1x1.4" (210x53x35mm)	
Weight	5.8oz (164g)	

Ordering

MA160 200A True RMS AC/DC Open Jaw Clamp Meter



UPC Code: 793950316016