

# Power supply bench DEMO-AC & DC



ref. ALI-DEMO

Workbench for the study of motors ref. DEMO-AC and DEMO-DC.  
Fitted with a 1200 x 750mm worktop and a 250mm width electrical cabinet.  
High mechanical and high temperature resistance stratified worktop.

**The lateral console delivers below outputs:**

- variable 3-phase + N 0-48V / 15A per phase, usable in two-phase.
- variable DC 0-48V / 6A
- 12V DC / 4A
- 2 x 230V power sockets (2P+E)

**Common features for all outputs:**

- Hard-wearing LED lamp, without maintenance
- Emergency key release stop button, and start/stop push button
- Each output is controlled independently
- Outputs protected with circuit breakers or auto-protection with auto reset
- Outputs with voltmeter and ammeter
- Electrical drawing available on request.

**MOBILE VERSION WITHOUT TABLE**

Power supply on wheels.  
Consult us.

